Tonelify

CHEAT SHEET

Ampeg SVT Classic Settings Cheat Sheet

Tonelify's starting points, 5 = middle of the knob. Master to taste on every row.

	GAIN	BASS	MIDRANGE	TREBLE	MIDRANGE FREQUENCY	ULTRA HI SWITCH	ULTRA LO SWITCH	MASTER
Starting point ULTRAS OFF, MIDS 800 HZ	4	5	5	5	800 Hz			to taste
Rock growl MIDS 450 HZ	6 to 7	6	6 to 7	5	450 Hz		off	
Slap ULTRA LO AND ULTRA HI ON	4	5	4	5		on	on	
Fingerstyle MIDS 220 HZ	4	6	5	3	220 Hz	off		
Pick attack MIDS 1.6 KHZ, ULTRA HI ON	5 to 6	5	6	6	1.6 kHz	on		

INPUT	0 dB passive bass, -15 dB active bass.
ULTRA	Ultra Lo cuts mids, Ultra Hi adds top.
LOAD	2 or 4 ohms only. Never run without a cab.
STANDBY	Power first, wait 20 s, then Standby to ON.
SPEAKON	Use the Speakon jack near full power.
FAULT	LED flashing red and green: power tube.