Tonelify

CHEAT SHEET

Boss Katana 100 Gen 3 Settings Cheat Sheet

Four starting points. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE	PRESENCE	REVERB
Clean	 2 to 3	 5	 5	 6	 4 to 5	 about 3
Blues	 3 to 4	 5	 6 to 7	 5 to 6	 5	 about 3
Classic rock	 5 to 6	 5	 6 to 7	 6	 5	 about 2
Metal	 6 to 7	 5 to 6	 5	 6 to 7	 5 to 6	 1 or off

Clean — CLEAN, CAB VINTAGE · KEEP GAIN LOW

Blues — PUSHED · DIG IN FOR GRIT

Classic rock — CRUNCH, TRY CONTOUR · KEEP THE MIDS UP

Metal — LEAD OR BROWN, CAB MODERN · BOOST BEFORE GAIN

SAVE	Hold a CH button for one second.
BANK	Hold PANEL for a second to switch bank.
SOLO	SOLO on. Set its level in BOSS Tone Studio.
QUIET	POWER CONTROL to 0.5 W, not MASTER near zero.
PA	VOLUME sets the line out level, not MASTER.
FIZZY	Lower Gain first, then Presence, then Treble.

tonelify.com/gear/boss-katana-100-gen-3