Tonelify

CHEAT SHEET

Boss Katana 25 Settings Cheat Sheet

Four starting points. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE
Clean CLEAN · KEEP GAIN LOW	 2 to 3	 5	 5	 6
Blues PUSHED OR CRUNCH · DIG IN FOR GRIT	 3 to 4	 5	 6 to 7	 5 to 6
Classic rock CRUNCH · KEEP THE MIDS UP	 5 to 6	 5	 6 to 7	 6
Metal LEAD OR BROWN · BOOST BEFORE GAIN	 6 to 7	 5 to 6	 5	 6 to 7

EFFECTS	Press EFFECTS, turn VALUE to a block, press, turn.
SAVE	Hold EFFECTS (WRITE) for one second.
LEAD	Middle up a step, Delay, then TAP the time.
QUIET	POWER CONTROL to 0.5 W, not MASTER near zero.
TUNER	Hold the VALUE knob down.
FIZZY	Lower Gain first, then Treble.

tonelify.com/gear/boss-katana-25