Tonelify

CHEAT SHEET

Boss Katana-Air EX Settings Cheat Sheet

Clock positions, 12:00 is the middle. Press PANEL first.

	GAIN	VOLUME	BASS	MIDDLE	TREBLE
Clean CLEAN REVERB RED FOR SPRING, LOW	 9:00	 12:00	 12:00	 12:00	 1:00
Blues CRUNCH BST/MOD GREEN, BLUES DRIVE	 11:00 to 12:00	 12:00	 11:00	 1:00	 12:00
Classic rock LEAD, LOWER GAIN OR CRUNCH WITH OVERDRIVE	 12:00 to 1:00	 12:00	 12:00	 1:00 to 2:00	 1:00
Metal BROWN REVERB LOW OR OFF	 2:00	 11:00	 12:00 to 1:00	 11:00	 1:00
Lead LEAD DIGITAL OR ANALOG DELAY	 2:00	 12:00	 12:00	 1:00 to 2:00	 1:00

SAVE	Hold CH A or CH B for one second.
TEMPO	Press TAP two or more times at the song's tempo.
START	MASTER and VOLUME fully left first.
FIZZY	Lower Gain first, then Treble.
THIN	Raise Middle before you raise Gain.
RESET	Hold PANEL while you switch on.