Tonelify

CHEAT SHEET

EHX Holy Grail Settings Cheat Sheet

Tonelify's starting points. The EHX manual draws no settings.

	REVERB	MODE
Subtle spring TONELIFY'S START	 10:00	 Spring
Wet surf spring TONELIFY'S START	 3:00	 Spring
Hall ambience TONELIFY'S START	 11:00	 Hall
Big hall TONELIFY'S START	 2:00	 Hall
Flerb TONELIFY'S START	 12:30	 Flerb

REVERB	Works like a wet/dry control.
NOON	Subtle below 12:00, a fast rise above it.
SPRING	Recreates a guitar amp's spring reverb.
FLERB	Flanging combined with spatial reverb.
BATTERY	None. The pedal does not use batteries.
POWER	Use only the supplied 9.6 V DC adapter.

tonelify.com/gear/electro-harmonix-holy-grail