Tonelify

CHEAT SHEET

Fender '65 Deluxe Reverb Settings Cheat Sheet

Values as the dials read, 1 to 10. Reverb and vibrato: Vibrato channel only.

	VOLUME	TREBLE	BASS	REVERB	SPEED	INTENSITY
Clean VIBRATO CHANNEL, INPUT 1	3	5	4	2		
Edge of breakup VIBRATO CHANNEL, VOLUME 4 TO 5	4 to 5	5	4	2		
Cranked VIBRATO CHANNEL, VOLUME PAST 5	6 to 7	5	3	2		
Surf VIBRATO CHANNEL, REVERB UP	3	7	4	6 to 7		
Tremolo VIBRATO CHANNEL, FOOTSWITCH IN	3 to 4	5	4	2	5	4
Pedals NORMAL CHANNEL, INPUT 1	3 to 4	5	4			

VIBRATO	Needs the footswitch plugged in to work.
REVERB	Fully down switches it off.
INPUT 2	6 dB less gain, for hot pickups.
BREAKUP	Around 5 on Volume, depending on pickups.
MIDS	No Middle knob: a mid-boost pedal fills in.
HOME	No master: clean at home, drive from a pedal.

tonelify.com/gear/fender-65-deluxe-reverb