Tonelify

CHEAT SHEET

Fender '65 Princeton Reverb Settings Cheat Sheet

Values as the dials read, 1 to 10. One channel, Input 1 unless your pickups are hot.

	VOLUME	TREBLE	BASS	REVERB	SPEED	INTENSITY
Clean INPUT 1, VOLUME 2 TO 3	 2 to 3	 6	 4	 2		
Edge of breakup INPUT 1, VOLUME 4 TO 6	 4 to 6	 5	 4	 2		
Cranked INPUT 1, VOLUME 7 AND UP	 7 to 8	 5	 3	 2		
Surf INPUT 1, REVERB UP	 3	 7	 4	 6 to 7		
Tremolo SPEED AND INTENSITY	 3 to 4	 5	 4	 2	 5	 4
Pedals INPUT 1, CLEAN BASE	 3	 5	 4	 2		

BREAKUP	Clean 1 to 3, sweet spot 4 to 6, drive from 7.
INPUT 2	6 dB lower, for high-output guitars.
MIDS	No Middle knob and no master volume.
SWITCH	The footswitch turns reverb and vibrato on and off.
STANDBY	None: only a power switch.
HOME	Clean at home, drive from a pedal.