Tonelify

CHEAT SHEET

Fender Champion 20 Settings Cheat Sheet

Pick the voice and the effect first. Knobs 0 to 10, 5 at noon.

	GAIN	TREBLE	BASS	FX LEVEL
Clean VOICE 04, '65 TWIN-AMP FX 04, REVERB SPRING	 3	 6	 5	 about 3
Country VOICE 04, '65 TWIN-AMP FX 08, DELAY SLAPBACK	 2 to 3	 7	 4	 about 3
Blues VOICE 02, TWEED DELUXE FX 04, REVERB SPRING	 5 to 6	 6	 4	 about 2
Classic rock VOICE 08, 70S BRITISH FX 03, REVERB HALL	 6	 6	 5	 about 2
Metal VOICE 11, 90S METAL FX 01, EFFECTS OFF	 7	 6	 6	
Jazz VOICE 05, '65 DELUXE FX 04, REVERB SPRING	 2	 3 to 4	 6	 about 2

LEVEL	Keep Gain low and set the loudness with Volume.
MIDS	There is no mid knob, so change the voice instead.
SOLO	FX 09, Delay Long. Press TAP in time, twice or more.
LEAD	Voice 10, Super-Sonic, is the one to try for leads.
FIZZY	On a metal voice, lower Treble before Gain.
SMEAR	Lower Gain a step before you touch Bass.

tonelify.com/gear/fender-champion-20