Tonelify

CHEAT SHEET

JHS Morning Glory V4 Settings Cheat Sheet

Four starts from Tonelify; JHS gives no knob positions.

	VOLUME	DRIVE	TONE	GAIN SWITCH	BRIGHT CUT SWITCH
Clean boost TONELIFY'S START	 1:00	 8:00	 12:00	 down	
Low-gain grit TONELIFY'S START	 12:00	 11:00	 11:00	 down	
Crunch boost TONELIFY'S START	 2:00	 10:00	 12:00	 down	
Gain lead TONELIFY'S START	 11:00	 1:00	 12:00	 up	 on

GAIN	Toggle up for more gain.
BRIGHT	Side switch cuts top end.
DRIVE	More drive is brighter too.
REMOTE	Red Remote flips the mode.
POWER	9V DC only, 43mA.
CHAIN	Before modulation and delay.

tonelify.com/gear/jhs-morning-glory