Tonelify

CHEAT SHEET

Marshall Origin 20C Settings Cheat Sheet

Set the power switch and the boost first. Knobs 0 to 10, 5 at noon.

	GAIN	TILT*	BASS	MIDDLE	TREBLE	PRESENCE	MASTER
Clean HIGH POWER, BOOST OFF	2 to 3	3	5	5	6	5	
Blues HIGH OR MID POWER, BOOST OFF	4 to 5	5	5	6	6	5	
Classic rock MID OR LOW POWER, MASTER UP	7 to 8	6	5	7	6	6	6 to 8
Hard rock GAIN BOOST ON	7 to 8	6	4 to 5	7	6	6	
Metal DRIVE PEDAL IN FRONT, BOOST OFF	4 to 5	5	5	6	6	6	

* Tilt: Normal to high treble

TILT	Low keeps the cleans round, turning it up adds sparkle.
BOOST	Pull the Gain knob out, or press the footswitch.
LOOP	The foot switch must be plugged in for the fx loop to work.
CRUNCH	Higher Master settings overdrive the power amp.
QUIET	Low power is about 0.5W, for home practice.
FIZZY	Lower Tilt before Treble.