Tonelify

CHEAT SHEET

Positive Grid Spark 40 Settings Cheat Sheet

Five starting points. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MID	TREBLE	REVERB	DELAY
Clean BLACK DUO AMP TYPE CLEAN	 2 to 3	 5	 5	 6	 about 3	
Blues LUX VERB OR BLUES BOY AMP TYPE CRUNCH	 3 to 4	 5	 6 to 7	 5 to 6	 about 3	
Classic rock PLEXIGLAS OR JM45 AMP TYPE CRUNCH	 5 to 6	 5	 6 to 7	 6	 about 2	
Metal INSANE OR TREADPLATE NOISE GATE ON	 6 to 7	 4 to 5	 5	 6 to 7	 1 or off	
Lead SLO 100 DELAY TIMED ON TAP	 6	 5	 6 to 7	 6	 about 2	 about 3

SAVE	Hold a preset button. A flashing LED means unsaved.
MODELS	Amp Type changes the model; the app reaches the rest.
FX	Mod, Delay, Reverb set how much. Types are in the app.
TUNER	Hold TAP/TUNER. The amp is muted while tuning.
TEMPO	Tap TAP more than twice to set the delay time.
FIZZY	Lower Gain first. Past 7 adds fizz, not weight.