Tonelify

CHEAT SHEET

Positive Grid Spark GO Settings Cheat Sheet

Five starting points. Spark app knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE
Clean BLACK DUO KEEP GAIN LOW	 2 to 3	 5	 5	 6
Blues LUX VERB OR BLUES BOY OVER DRIVE OR TUBE DRIVE	 3 to 4	 5	 6 to 7	 5 to 6
Classic rock PLEXIGLAS OR JM45 KEEP THE MIDS UP	 5 to 6	 5	 6 to 7	 6
Metal INSANE OR TREADPLATE NOISE GATE ON	 6 to 7	 4 to 5	 5	 6 to 7
Lead SLO 100 DELAY ON TAP TEMPO	 6	 5	 6 to 7	 6

KNOBS	Amp and effect knobs are in the Spark app.
SAVE	Save to Hardware puts a tone in one of 4 slots.
TUNER	Hold Preset. The GO is muted while tuning.
LEVEL	Guitar Volume for you, Music Volume for songs.
EQ	EQ Scenario shapes the speaker, not headphones.
FIZZY	Lower Gain first. Past 7 adds fizz, not weight.