Tonelify

CHEAT SHEET

Positive Grid Spark NEO Settings Cheat Sheet

Five starting points. Spark app knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE
Clean BLACK DUO KEEP GAIN LOW	 2 to 3	 5	 5	 6
Blues LUX VERB OR BLUES BOY OVER DRIVE OR TUBE DRIVE	 3 to 4	 5	 6 to 7	 5 to 6
Classic rock PLEXIGLAS OR JM45 KEEP THE MIDS UP	 5 to 6	 5	 6 to 7	 6
Metal INSANE OR TREADPLATE NOISE GATE ON	 6 to 7	 4 to 5	 5	 6 to 7
Lead SLO 100 DELAY ON TAP TEMPO	 6	 5	 6 to 7	 6

KNOBS	Amp and effect knobs are in the Spark app.
SAVE	Save to Hardware puts a tone in one of 4 slots.
SLOT	The app shows CH1 to CH4. The headphones don't.
LEVEL	Guitar Volume + and - work only while you play.
MUSIC	Set the music level on the phone, not the NEO.
MUTE	Tap the transmitter's power button once.