Tonelify

CHEAT SHEET

# Roland JC-120 Jazz Chorus Settings Cheat Sheet

Starting points on the 0 to 10 knobs. Reverb and effects: Channel 2 only.

| | TREBLE | MIDDLE | BASS | REVERB | VOLUME | SPEED | DEPTH | DISTORTION |
|---|---|---|---|---|---|---|---|---|
| **Clean**<br>CHANNEL 1, BRIGHT OFF | 6 | 5 | 4 to 5 | | to taste | | | |
| **Chorus**<br>CHANNEL 2, CHORUS | 6 | 5 | 4 to 5 | 2 to 3 | | | | |
| **Vibrato**<br>CHANNEL 2, VIB | 6 | 5 | 4 to 5 | 2 to 3 | | 3 to 4 | 3 to 5 | |
| **Jazz**<br>CHANNEL 2, EFFECTS OFF | 3 to 4 | 5 to 6 | 5 to 6 | about 2 | | | | |
| **Crunch**<br>CHANNEL 2, DISTORTION | 4 to 5 | 6 | 5 | about 2 | | | | 4 to 6 |

| | |
|---|---|
| CHORUS | Fixed speed and depth: the knobs are for vibrato. |
| STEREO | Hear the chorus from a few steps back. |
| INPUT | High for most guitars, Low for hot pickups. |
| LOOP | Series or Parallel, Channel 2 only. |
| SWITCH | BOSS FS-5L, FS-6 or FS-7. |
| PEDALS | Distortion OFF, drive from the pedal. |