Tonelify

CHEAT SHEET

Strymon BigSky Settings Cheat Sheet

Knob positions as a clock, 12:00 = straight up. Decay is read on the display, in seconds.

	TYPE	DECAY	MIX	TONE	MOD	PRE-DELAY
Hall HALL, CONCERT	 Hall	 about 3.5 s	 10:00	 12:00	 12:00	 9:00
Spring SPRING, 2 SPRINGS, COMBO	 Spring	 about 4.5 s	 11:00	 10:00		
Surf SPRING, LOW END MIN	 Spring	 about 4.5 s	 3:00	 max		
Plate PLATE, LARGE	 Plate	 about 1.5 s	 9:00	 12:00		
Ambient ROOM	 Room	 12 s or more	 to taste		 1:00	 12:00
Shimmer SHIMMER, +OCT AND +OCT 5TH	 Shimmer	 about 6 s	 11:00	 12:00	 12:00	

MIX	3:00 = 50/50 dry and wet.
TONE	12:00 = balanced top end.
PARAM	Hold Value, turn Param to assign.
SAVE	Hold Type, then push Type to save.
TRAILS	Persist on for trails after bypass.
CAB	Cab Filter On only with no amp.