Tonelify

CHEAT SHEET

Vox AC30C2 Settings Cheat Sheet

Starting points on the knobs, 5 = 12 o'clock. Reverb and tremolo work on both channels.

	REVERB LEVEL	TONE CUT	MASTER	TOP BOOST TREBLE	REVERB TONE	TOP BOOST VOLUME	TOP BOOST BASS	NORMAL VOLUME	TREMOLO DEPTH	TREMOLO SPEED
Clean NORMAL CHANNEL	2	3	to taste		5			3 to 4		
Chime TOP BOOST CHANNEL	2 to 3	4	to taste	5	5	3	5			
Blues TOP BOOST CHANNEL	2	5	4	5		5 to 6	5			
Crunch TOP BOOST, PUSHED	1	6	3	6		7 to 8	4			
Wet reverb EITHER CHANNEL	6 to 7	4		5	6 to 7					
Tremolo EITHER CHANNEL	2 to 3								4 to 5	3 to 5

TONE	Tone Cut up = darker, down = brighter.
EQ	Treble cuts Bass: set Treble first.
DRIVE	Channel volume up, Master down.
LOOP	Delay in the loop, drive in front.
SWITCH	VFS2A: reverb and tremolo on/off.
STANDBY	Power on, wait 2 to 3 min, then Standby.