Tonelify

CHEAT SHEET

Vox VT20X Settings Cheat Sheet

Manual mode. Knobs 0 to 10, 5 = 12 o'clock.

	GAIN	TREBLE	MIDDLE	BASS	VOLUME
Clean DELUXE CL SPRING REVERB LOW	 3	 6	 5	 5	 5
Blues TWEED 4X10 GUITAR VOLUME FOR CLEAN	 6	 6	 6	 4	 6
AC30 crunch VOX AC30TB BIAS SHIFT RED (HOT)	 5	 6	 5	 5	 6
Classic rock USER B, BRIT 1959 POWER LEVEL FOR LOUDNESS	 6	 6	 7	 5	 8
Metal USER C, BOUTIQUE METAL BIAS SHIFT GREEN (COLD)	 7	 6	 4	 6	 5
Lead BRIT OR MKII TAPE ECHO, TAP THE TIME	 7	 6	 7	 5	 6

MANUAL	Hold PRESET PROGRAMS 1 s for Manual mode.
ORDER	Pick the model first: it resets Bias and Class.
QUIET	POWER LEVEL keeps the tone at low volume.
SAVE	Hold BANK, pick a bank, hold a channel 2 s.
TUNER	Hold TAP for one second.
PHONES	Headphones mute the speaker.

tonelify.com/gear/vox-vt20x