Tonelify

CHEAT SHEET

Boss Katana Settings Cheat Sheet

Starting points for each amp type. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE	PRESENCE*	REVERB
Clean CLEAN AMP TYPE	 2 to 3	 5	 5	 6	 4 to 5	 about 3
Blues CRUNCH AMP TYPE	 3 to 4	 5	 6 to 7	 5 to 6	 5	 about 3
Classic rock CRUNCH AMP TYPE	 5 to 6	 5	 6 to 7	 6	 5	 about 2
Metal LEAD OR BROWN AMP TYPE	 6 to 7	 5 to 6	 5	 6 to 7	 5 to 6	 1 or off

* Presence: 100-watt models only

BOOST	For metal, add Mid Boost and take the Gain down a step.
LEAD	Your rhythm sound, Middle up a step, Delay and a little Reverb.
FIZZY	Lower Gain first, then Presence, then Treble.
THIN	Raise Middle before you raise Gain.
MUDDY	Lower Bass and try the other Variation.
SAVE	Hold a channel button for one second. Master is not stored.

tonelify.com/guides/boss-katana-settings