Tonelify

CHEAT SHEET

Fender Champion Settings Cheat Sheet

Pick the voice and the effect first. Knobs 0 to 10, 5 at noon.

	GAIN	TREBLE	BASS	FX LEVEL*
Clean '65 TWIN VOICE SPRING REVERB	 3	 6	 5	 about 3
Country '65 TWIN VOICE SLAPBACK DELAY	 2 to 3	 7	 4	 about 3
Blues TWEED DELUXE OR BASSMAN SPRING REVERB	 5 to 6	 6	 4	 about 2
Classic rock 70S BRITISH VOICE HALL REVERB	 6	 6	 5	 about 2
Metal A METAL VOICE EFFECTS OFF	 7	 6	 6	
Jazz '65 DELUXE VOICE SPRING REVERB	 2	 3 to 4	 6	 about 2

* FX Level: Modify on a Champion II

VOICE	Find the voice by name: the numbers differ by model.
LEVEL	Keep Gain low and set the loudness with Volume.
MODIFY	Champion II: Modify sets a reverb or delay's level.
MID	The 100s, channel 2: Mid 5, or 6 to 7 for rock.
TAP	Press TAP in time, twice or more, for the delay.

tonelify.com/guides/fender-champion-settings