Tonelify

CHEAT SHEET

Vox AC10 Settings Cheat Sheet

Vox AC10C1, one channel. 5 = 12 o'clock.

	GAIN	BASS	TREBLE	REVERB	VOLUME
Clean GAIN LOW, VOLUME HIGH	 3	 5	 5	 3	 6
Chime TREBLE UP, BASS DOWN	 4	 4	 6	 2	 5
Blues EDGE OF BREAKUP	 6	 5	 5	 2	 4
Crunch GAIN HIGH, VOLUME LOW	 8	 4	 6	 1	 3

CLEAN	Lower Gain, raise Volume for a cleaner sound.
DRIVE	Gain up, Volume down: more drive, less level.
BASS	Past 6 it booms: add Gain for weight.
CAB	External jack: 16 Ohm cab, mutes the speaker.
ECO	230V amps power off after 20 min of silence.

tonelify.com/guides/vox-amp-settings