Tonelify

CHEAT SHEET

Fender Mustang LT40S Settings Cheat Sheet

Pick the amp model first. 0 to 10, as on the display.

	GAIN	TREBLE	BASS	MIDDLE*
Clean TWIN CLEAN OR DELUXE CLN SPRING 65 IN REV, LOW	 2 to 3	 6	 5	 5
Blues DELUXE DIRT OR BASSMAN BLUES DRIVE IN STOMP, GAIN LOW	 3 to 4	 5 to 6	 5	 6 to 7
Classic rock 70S ROCK REVERB LOW	 5 to 6	 6	 5	 6 to 7
Metal SUPER HEAVY OR METAL 2000 METAL GATE ON METAL 2000	 6 to 7	 6 to 7	 4 to 5	 5
Hard rock 80S ROCK DELAY TIME: PRESS TAP	 6 to 7	 6	 5	 6 to 7

* Middle: no knob, set it from the encoder

MIDDLE	Press the encoder on the amp model, turn to MIDDLE.
SAVE	Press SAVE or the edit is lost when you leave.
TEMPO	Press TAP two or more times at the song's tempo.
TUNER	Hold TAP. The speaker is muted while you tune.
FIZZY	Lower Gain first, then Treble.
USB	Recording level: MENU, SETTINGS, USB GAIN.

tonelify.com/gear/fender-mustang-lt40s