Tonelify

CHEAT SHEET

Boss CS-3 Settings Cheat Sheet

Clock positions. Start, compressor and limiter are BOSS's drawings.

	LEVEL	TONE	ATTACK	SUSTAIN
Start BOSS'S START, ALL AT NOON	 12:00	 12:00	 12:00	 12:00
Compressor BOSS'S DRAWING	 12:00	 12:00	 12:00	 1:00
Limiter BOSS'S DRAWING	 12:00	 12:00	 12:00	 8:00
Country TONELIFY'S	 12:00	 1:30	 2:00	 12:30
Lead TONELIFY'S	 12:00	 11:00	 11:00	 2:30

SUSTAIN	Clockwise for more sustain.
ATTACK	Clockwise keeps the pick attack.
LIMIT	Sustain low = limiter, per BOSS.
NOISE	Howling? Sustain back a little.
LEVEL	Fully left gives no sound.

tonelify.com/gear/boss-cs-3