Tonelify

CHEAT SHEET

Boss GX-1 Settings Cheat Sheet

Five amp types. Gain 0 to 120, the rest 0 to 100.

	GAIN	BASS	MIDDLE	TREBLE
Clean TWIN SPRING REVERB, LOW	 30	 50	 50	 60
Blues DELUXE BLUES OD IN OD/DS	 50	 45	 60	 55
Classic rock BRIT STACK KEEP THE MIDS UP	 65	 50	 65	 55
Metal RECTI STACK T-SCREAM IN OD/DS FIRST	 80	 60	 40	 60
Lead X-HI GAIN AMP SOLO ON CTL1	 70	 50	 70	 55

SAVE	EXIT and ENTER together, WRITE, pick U01 to U99.
TUNER	Press the UP and DOWN switches together.
LOOPER	UP and CTL1 together; CTL1 records and plays.
SUITE	EDIT, pick the block, turn knob 3 for Gear Suite.
GATE	Raise NS THRESHOLD until the hiss goes.
AMP	MENU, OUTPUT SELECT: match your amp and jack.