Tonelify

CHEAT SHEET

Fender Mustang LT50 Settings Cheat Sheet

Pick the amp model first. 0 to 10, as on the display.

	GAIN	TREBLE	MIDDLE	BASS
Clean TWIN CLEAN OR DELUXE CLN SPRING 65 IN REV, LOW	 2 to 3	 6	 5	 5
Blues DELUXE DIRT OR BASSMAN BLUES DRIVE IN STOMP, GAIN LOW	 3 to 4	 5 to 6	 6 to 7	 5
Classic rock 70S ROCK REVERB LOW	 5 to 6	 6	 6 to 7	 5
Metal SUPER HEAVY OR METAL 2000 METAL GATE ON METAL 2000	 6 to 7	 6 to 7	 5	 4 to 5
Hard rock 80S ROCK DELAY TIME: PRESS TAP	 6 to 7	 6	 6 to 7	 5

SAVE	Press SAVE or the edit is lost. 30 slots start empty.
TEMPO	Press TAP two or more times at the song's tempo.
TUNER	Hold TAP. The speaker is muted while you tune.
FIZZY	Lower Gain first, then Treble.
THIN	Raise Middle before you raise Gain.
LINE	USB and line out level: MENU, LEVELS.