Tonelify

CHEAT SHEET

Hartke HD75 Settings Cheat Sheet

Clock positions. Row one is Hartke's quick start; the other clock positions are Tonelify's.

	VOLUME	BASS	MID	TREBLE	7-BAND GRAPHIC EQ
Flat start SLIDERS AT CENTER					
Reggae HARTKE: BASS UP, TREBLE DOWN					
Hi-fi HARTKE: MID DOWN					
Twang HARTKE: TREBLE UP, BASS DOWN					
Rock pick 63 HZ DOWN, 1.25 KHZ UP					

START	Volume at zero, bass output at max.
LOWS	Too much low boost can distort.
SLIDERS	Center detent = no effect.
PEDALS	Stomp boxes before the Input.
PHONES	Headphones mute the speaker.
AUX	Set the balance on the player.