Tonelify

CHEAT SHEET

IK Multimedia TONEX Pedal Settings Cheat Sheet

Tonelify's starting points per kind of Tone Model, on the pedal's 0 to 10 scale.

	GAIN	BASS	MID	TREBLE
Clean CLEAN TONE MODEL	 3 to 4	 5	 5	 6
Edge of breakup CLEAN OR CRUNCH MODEL	 5 to 6	 4 to 5	 6	 5
Classic rock DRIVE TONE MODEL	 5 to 6	 5	 6 to 7	 6
Metal HIGH-GAIN TONE MODEL	 4 to 5	 4 to 5	 5 to 6	 6
Drive pedal STOMP MODEL, CAB OFF	 3 to 4	 5	 6	 5

TRIM	TRIM IN: raise to HI, back to OK.
ALT	Hold PARAMETER: reverb, comp, gate.
VOLUME	Master for all presets. MODEL.VOL per preset.
CAB	Real cabinet? Bypass the cab.
SAVE	Hold PRESET. MODEL + PRESET = quick save.
BANKS	A+B bank down, B+C bank up.

tonelify.com/gear/ik-multimedia-tonex-pedal