Tonelify

CHEAT SHEET

POD HD500X Settings Cheat Sheet

Five HD amp models. Knob positions as the screen shows them.

	DRIVE	BASS	MID	TREBLE	PRESENCE
Clean BLACKFACE DOUBLE VIBRATO 212 BLACKFACE DOUBLE CAB	 10:00	 12:00	 11:00	 1:00	 12:00
Blues TWEED B-MAN BRIGHT 410 TWEED CAB, SAG UP	 1:00	 11:00	 1:00	 12:00	 12:00
Classic rock PLEXI LEAD 100 BRIGHT 412 GREENBACK 25 CAB	 2:00	 11:00	 2:00	 1:00	 12:00
Metal TREADPLATE 412 TREAD V-30, NOISE GATE FIRST	 2:00	 1:00	 10:00	 1:00	 1:00
Lead SOLO 100 OD 412 BRIT T-75, ANALOG ECHO	 1:00	 12:00	 2:00	 12:00	 11:00

SAVE	SAVE, pick Set List and place, SAVE again.
TUNER	Hold TAP; any footswitch to leave.
LOOPER	24 seconds, 48 at half speed.
AMP	Combo or Stack output mode into an amp.
PEDAL	Toe switch toggles EXP 1 and EXP 2.
DSP	Pitch and reverb models use the most.

tonelify.com/gear/line-6-pod-hd500x