Tonelify

CHEAT SHEET

Marshall MG30GFX Settings Cheat Sheet

Starting points on the knobs, 5 = 12 o'clock. Press Store to keep each one in its channel.

	GAIN	BASS	MIDDLE	TREBLE	REVERB	VOLUME	MASTER	FX
Clean	CLEAN CHANNEL							
	 3	 5	 5	 6	 3	 5	 to taste	 off
Crunch	CRUNCH CHANNEL							
	 5 to 6	 5	 6	 6	 2	 5	 to taste	
Rock lead	OD-1 CHANNEL							
	 6	 5	 7	 6	 2	 6	 to taste	 delay, low
Metal	OD-2 CHANNEL							
	 7 to 8	 6	 4	 6	 1	 5	 to taste	 off

STORE	Press Store before you change channel.
MODE	Hold Tap 2 s: Preset or Manual mode.
FX	One knob picks the effect and its level.
TAP	Tap twice on the beat for delay time.
RESET	Hold Store at power on until green.
PEDALS	No loop: all pedals go in front.

tonelify.com/gear/marshall-mg30gfx