Tonelify

CHEAT SHEET

Mesa/Boogie Mark V:25 Settings Cheat Sheet

Clock positions, 12:00 is the middle. Two channels, three modes each.

	GAIN	TREBLE	BASS	PRESENCE	MASTER	CHANNEL 1 MID/BOOST	CHANNEL 2 MID
Clean CHANNEL 1, CLEAN MODE 25 W, EQ OFF	 10:00 to 11:00	 12:00	 11:00	 11:00 to 12:00	 10:00 to 10:30	 9:00	
Fat blues CHANNEL 1, FAT MODE 10 W	 12:00 to 1:00	 12:00	 9:00 to 10:00	 10:00 to 11:00	 10:00	 1:00	
Crunch CHANNEL 1, CRUNCH MODE 25 W	 11:00 to 12:00	 1:00	 10:00	 11:00	 10:00	 10:00 to 11:00	
Lead CHANNEL 2, MK IIC+ MODE 25 W	 12:30 to 1:00	 12:00	 10:30	 9:30 to 10:00	 10:00		 11:00 to 12:00
Xtreme metal CHANNEL 2, XTREME MODE EQ ON	 1:00 to 2:00	 12:00 to 1:00	 10:00	 10:30 to 11:00	 9:30 to 10:00		 10:00 to 11:00

GAIN	Lower than on a big amp: the EL84s add drive.
MID/BST	Up to noon a mid knob, past it a gain boost.
WATTS	Each channel: 25 W or 10 W.
EQ	Up on, center off, down on the footswitch.
REVERB	Per channel, on the back panel.
SWITCH	Center toggle on FS for the footswitch.