Tonelify

CHEAT SHEET

MXR Dyna Comp Settings Cheat Sheet

Clock positions. Three are MXR's drawn samples, read to the nearest half hour.

	OUTPUT	SENSITIVITY
Start MXR'S START, ALL AT 12	 12:00	 12:00
Nashville MXR'S DRAWING	 3:30	 10:30
New wave MXR'S DRAWING	 3:30	 1:00
Slide MXR'S NASTY BOTTLENECK	 5:00	 5:00
Always on TONELIFY'S	 1:00	 9:00

SENS	Sensitivity sets the compression ratio.
OUTPUT	Set Output so it is as loud on as off.
NOISE	More Sensitivity brings up the noise too.
ATTACK	Fixed: 5 ms attack, 1 s release.
POWER	9 V battery or adapter, 3.3 mA.