Tonelify

CHEAT SHEET

Orange Rocker 15 Settings Cheat Sheet

Pick the channel and power first. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MIDDLE	TREBLE	NATURAL VOLUME*
Clean NATURAL CHANNEL, FULL POWER					 3 to 4
Blues NATURAL CHANNEL, HALF POWER					 5 to 7
Classic rock DIRTY CHANNEL, MIDDLE UP	 4 to 5	 5	 7	 6	
Hard rock DIRTY CHANNEL, FULL POWER	 6 to 7	 5	 6	 6	
Metal DIRTY CHANNEL, GAIN HIGH	 8 to 9	 6	 5	 5	

* Natural Volume: Natural channel only

EQ	Bass, Middle and Treble only affect the Dirty channel.
NATURAL	No master: the power valves overdrive as Volume goes up.
HALF	Half power gets the same breakup at a lower volume.
BEDROOM	The back switch takes it to 1W, or 0.5W at Half.
SILENT	No sound on Dirty? Gain at minimum mutes it.
FIZZY	At low power, lower Treble before Gain.