Tonelify

CHEAT SHEET

Peavey 6505+ Settings Cheat Sheet

Tonelify's starting points on a 0 to 10 scale.

	PRE	LOW	MID	HIGH	RESONANCE	PRESENCE
Clean RHYTHM CHANNEL · PRE 0 TO 4, BRIGHT IN	 3	 5	 5	 6	 4	 4
Crunch RHYTHM CHANNEL · CRUNCH IN	 6	 5	 6	 6	 4	 5
Metal rhythm LEAD CHANNEL · PRE AT THE LOW END OF 5 TO 10	 6	 6	 4	 6	 5	 5
Lead LEAD CHANNEL · MID UP, POST UP	 7	 5	 7	 5	 4	 5

OHMS	Two equal cabs: half the value.
LOOP	Non-gain effects only.
REMOTE	Press Channel Select in first.
CAB	Tune Resonance to the cab.
RECORD	Preamp Out, +10 dBV.
HUM	Ground Switch to + or -.

tonelify.com/gear/peavey-6505-plus