Tonelify

CHEAT SHEET

Positive Grid Spark 2 Settings Cheat Sheet

Five starting points. Knobs 0 to 10, 5 at noon.

	GAIN	BASS	MID	TREBLE	REVERB	DELAY
Clean BLACK DUO KEEP GAIN LOW	 2 to 3	 5	 5	 6	 about 3	
Blues LUX VERB OR BLUES BOY OVER DRIVE OR TUBE DRIVE	 3 to 4	 5	 6 to 7	 5 to 6	 about 3	
Classic rock PLEXIGLAS OR JM45 KEEP THE MIDS UP	 5 to 6	 5	 6 to 7	 6	 about 2	
Metal INSANE OR TREADPLATE NOISE GATE ON	 6 to 7	 4 to 5	 5	 6 to 7	 1 or off	
Lead SLO 100 DELAY TIMED ON TAP	 6	 5	 6 to 7	 6	 about 2	 about 3

MODEL	No Amp Type knob: pick the model in the Spark app.
SAVE	Save to Hardware in the app puts it in a slot.
BANKS	Press PRESET to swap the red and green banks.
FX	Mod, Delay, Reverb set how much. Types are in the app.
TUNER	Hold TAP/TUNER. The amp is muted while tuning.
FIZZY	Lower Gain first. Past 7 adds fizz, not weight.