Tonelify

CHEAT SHEET

TC Electronic Flashback 2 Delay Cheat Sheet

Four delay starts from Tonelify; TC gives no knob positions.

DELAY TYPE	DELAY	FEEDBACK	LEVEL	SUBDIVISION SWITCH
Slapback TONELIFY'S START	 Analog	 8:00	 8:00	 12:00	 quarter note
Dotted eighth TONELIFY'S START	 2290	 12:00	 10:00	 11:00	 dotted eighth
Tape lead TONELIFY'S START	 Tape	 11:00	 11:00	 11:00	 quarter note
Crystals TONELIFY'S START	 Crystals	 2:00	 1:00	 10:00	 quarter plus dotted eighth

MASH	Press harder and hold.
LOOP	Up to 40 s mono, 20 s stereo.
TP3	Silent by default; use MASH.
TAP	Firmware 1.2 or a tap switch.
POWER	9 V, over 100 mA.
CHAIN	After drive pedals.

tonelify.com/gear/tc-electronic-flashback-2