Tonelify

CHEAT SHEET

Bass Amp Settings Cheat Sheet

Ampeg BA-110. Clock positions, 12:00 is flat. Volume to taste.

	BASS	MID	TREBLE	DRIVE	BLEND
Flat ALL THREE AT CENTRE	 12:00	 12:00	 12:00	 off	 off
Rock SCRAMBLER ON	 1:00	 1:00	 12:00	 11:00	 10:00
Slap MID DOWN	 1:00	 10:00	 1:00	 off	 off
Fingerstyle TREBLE DOWN	 1:00	 12:00	 10:00	 off	 off

START	Volume down, bass at full, then up slowly.
CUT	Cut a band before you boost another.
LOWS	Too much low boost can distort.
ACTIVE	Hot or active bass: use the -15 dB pad.
PHONES	Headphones mute the speaker.