Tonelify

CHEAT SHEET

Fender Frontman Settings Cheat Sheet

Dials numbered 1 to 10. Volume to taste on every setting.

	TREBLE	BASS	GAIN	MIDDLE*
10G clean O.D. OUT	 6	 5		
10G crunch O.D. IN	 6	 5	 4	
10G rock, metal O.D. IN	 7	 6	 8	
20G clean NORMAL CHANNEL	 6	 5		 5
20G crunch DRIVE CHANNEL	 6	 5	 4	 6
20G metal DRIVE CHANNEL	 7	 6	 8	 4

* Middle: 20G only

O.D.	On a 10G, Gain only works with O.D. pressed in.
FIZZ	Lower Treble before Gain.
THIN	Raise Middle on a 20G, Bass on a 10G.
EQ	One EQ for both 20G channels: set it for the main one.
RECORD	20G and 25R headphone jacks double as a line out.

tonelify.com/guides/fender-frontman-settings