Tonelify

CHEAT SHEET

Fender Twin Reverb Settings Cheat Sheet

Fender '65 Twin Reverb, Vibrato channel. Dials read 1 to 10.

	VOLUME	TREBLE	MIDDLE	BASS	REVERB
Clean VIBRATO CHANNEL, BRIGHT OFF	 3	 5	 4	 4	 2
Bright VIBRATO CHANNEL, BRIGHT ON	 2	 4	 5	 4	 3
Surf VIBRATO CHANNEL, REVERB UP	 3	 7	 4	 4	 6 to 7
Breakup VIBRATO CHANNEL, VOLUME UP	 5 to 6	 5	 5	 3	 2

INPUT	Input 2 is 6 dB lower, for hot pickups.
BRIGHT	Bright adds most at low Volume.
VIBRATO	Vibrato needs the footswitch plugged in.
TONE	Tone knobs all at zero: no sound.
LOAD	Keep a 4 ohm speaker load connected.