Tonelify

CHEAT SHEET

Marshall DSL Settings Cheat Sheet

DSL40CR and DSL100HR. One EQ for both channels.

	GAIN	TREBLE	MIDDLE	BASS	PRESENCE
Clean CLASSIC, CLEAN MODE	 3 to 4	 6	 5	 5	 5
Crunch CLASSIC, CRUNCH MODE	 5 to 7	 6	 6 to 7	 5	 6
Hard rock ULTRA, OD1	 5 to 6	 6	 6	 5	 6
Metal ULTRA, OD2, TONE SHIFT	 6 to 7	 6	 5	 6	 6

GAIN	Gain sets the drive; Volume and Master the loudness.
EQ	One EQ for both channels: set it for the one you use most.
FIZZ	Fizzy? Bring Presence down before Treble.
SOLO	Set Master 2 above Master 1 for a solo boost.
QUIET	Output switch: 40W to 20W, 100W to 50W.

tonelify.com/guides/marshall-dsl-settings